



**El control intuitivo de la cámara, que facilita el uso y la visibilidad**

## **AW-RP150GJ**

El AW-RP150 es el último modelo de controlador de cámaras remotas que se incorpora a la completa gama de cámaras PTZ profesionales de Panasonic.

### **Key Features**

---

Pantalla táctil de gran tamaño para mayor facilidad de uso

---

Nuevo joystick que se maneja con una sola mano

---

Ajustes preestablecidos simplificados para la cámara PTZ y memoria de seguimiento

---

Elementos de diseño intuitivos basados en los comentarios directos de los operadores de cámaras robóticas que las utilizan a diario

---

Salidas activas 3G-SDI, 5 x RS-422, LAN PoE+, 2 x GPIO



## AW-RP150GJ

<https://latam.connect.panasonic.com/co/es/productos/broadcast-y-proav/aw-rp150gj>

### General

<b>Power Requirements</b>	12 V DC (10.8 V to 13.2 V)
<b>PoE+</b>	IEEE802.3at standard: DC 42 V to 57 V (Camera Input)
<b>Current Consumption</b>	1.0 A (Connector Input) 0.6 A (PoE+ power supply)
<b>Ambient Operating Temperature</b>	0 °C to 40 °C (32 °F to 104 °F)
<b>Ambient Operating Humidity</b>	20% to 90% (no condensation)
<b>Storage Temperature</b>	-20 °C to 50 °C (-4 °F to 122 °F)
<b>Peso</b>	Approx. 3.2 kg (7.05 lb)
<b>Dimensions (W x H x D) (mm)</b>	342 mm x 178 mm x 245 mm(excluding protrusions)
<b>Dimensions (W x H x D) (inch)</b>	13-15/32 inches x 7 inches x 9-21/32 inches(excluding protrusions)
<b>Controller Supported Equipment</b>	IP/RS422 AW-UE150W/K, AW-HR140*1, AW-HE130W/K*1, AW-HN130W/K*1, AW-UE70W/K*1, AW-UN70W/K*1, AW-HE40 Series*1, AW-HN40HW/HK*1, AW-HE38HW/HK*1, AW-HN38HW/HK*1

### Input/Output Connector

<b>Input</b>	DC 12 V IN XLR 4-pin  3G-SDI IN SMPTE292 / 75 Ω (BNC x 1) Supported formats: 1080/59.94p*2, 1080/50p*2, 1080/59.94i, 1080/50i, 1080/23.98p, 1080/25p, 1080/23.98PsF, 1080/25PsF
<b>Output</b>	ACTIVE THRU OUT SMPTE292 / 75 Ω (BNC x 1)
<b>Input/Output</b>	IP CONT:  =====
	100BASE-TX  -----
	PoE+ input  -----
	Connection cable: LAN cable, max. 100 m (328 ft)  • When connecting the unit via a switching hub:  Straight cable or a cross cable (category 5 cable), STP (Shielded Twisted Pair) cable recommended  • When connecting the unit directly: Crossover cable (category 5 cable), STP (Shielded Twisted Pair) cable recommended  =====
	SERIAL CONT (RJ-45):

=====

RS-422 (control signals for remote cameras), TALLY OUT

-----

Connecting cable:

Straight cable (category 5e or better shielded cable), max. 1000 m (3280 ft)

-----

TALLY OUT: Open collector output (negative logic)

Maximum voltage resistance DC 24 V, Maximum current 50 mA

=====

TALLY/GPIO 1

=====

D-sub 25-pin, female, inch thread

-----

TALLY IN : 10 inputs (for receiving photocoupler signals)

-----

GPI : 6 inputs (for receiving photocoupler signals)

GPIO : 5 inputs (for receiving photocoupler signals)

or 5 outputs (open collector outputs, negative logic)

- Input/output switched with menu settings

=====

GPIO 2

=====

D-sub 25-pin, female, inch thread

-----

GPI : 10 inputs (for receiving photocoupler signals)

GPIO : 10 inputs (for receiving photocoupler signals) or 10 outputs (open collector outputs, negative logic)

- Input/output switched with menu settings

Reserve connectors:

2 connectors (For future expansion feature)

---

**LCD Display** 7-inch Touch Panel GUI Monitor (WGA (800×480))

---

**SD Memory Card Slot** SDHC / SDXC Memory Card Slot x 1

---

**Connection Specifications**

---

**No. of Connectable Cameras** 200 (IP), 5 (RS422)

---

**No. of Camera Selection Buttons** 10

---

**No. of Camera Groups** 20 (10 units per 1 group)

---

**Memory**

---

**Preset Memory** No. of memory : presets 100

---

**Tracing Memory** No. of cameras : Cam1 to Cam10

---

Recording time, no. of memory settings : Maximum 5 min. total per camera, maximum of 10 settings per camera

---

**Other Functions**

---

**No. of User Assignable Buttons** 6 + up to 10 on the LCD menu

---

**Pan / Tilt Speed Adjustment** 7 levels

---

**Tally LED display color** green / red

---

**Note**

---

\*1: Connection with the AW-RP150Gj is planned for future support. Contact your sales representative for further information on when support will be available for this feature. Use may require a software version update. \*2: Level-A support only.