## Panasonic CONNECT



Conveniently Compact Switcher Achieves Highquality Video

## **AV-HSW10**

IP Live Switcher with intuitive and compact design takes online communication one level higher.

## **Key Features**

Diverse Interfaces to Suit Wide-ranging Needs

Diverse Keyers for More Attractive Video

Multiviewer With 10 Selectable Patterns

Remote Control With Software Control Panel



## AV-HSW10

https://latam.connect.panasonic.com/pe/es/productos/broadcast-y-proav/av-hsw10

Live Switcher -> General -> Power Supply	16 V Dedicated Adaptor
Live Switcher -> General -> Power Consumption	3.0 A (48 W)
Live Switcher -> General -> Operating Temperature	g 0°C to 40 °C (32 °F to 104 °F)
Live Switcher -> General -> Operating	<b>g</b> 10 % to 90 % (no condensation)
Live Switcher -> General -> Storage Temperature	0 °C to 40 °C (32 °F to 104 °F)
Live Switcher -> General -> Storage Humidity	10 % to 90 % (no condensation)
Live Switcher -> General -> Weight	Approx. 1.8 kg (Approx.3.96 lb)
Live Switcher -> General -> Dimensions	W 254 mm x H 67 mm x D 175 mm
	(10 inches x 2-5/8 inches x 6-7/8 inches)
	(excluding protrusions)
Live Switcher -> General -> ME	1 ME
Number	
Live Switcher -> Video Terminal -> SD	I 4 lines
IN	
	• Connectors: BNC x 4
	• Equipped with frame synchronizer
	• Connectors and have simplified format simple format converters, and have high-performance format converters.
	Connectors to are equipped with simplified format converters.
	*SDI IN 1 excludes HDMI IN1.
	[3G-SDI] 3G-SDI, SMPTE424 standard complied with (Compatible with Level-A/Level-B)
	· 0.8 V [p-p] ± 10 % (75 Ω)
	• Automatic equalizer 100 m (when using a cable)
	[HD-SDI] HD-SDI, SMPTE292M standard
	• 0.8 V [p-p] ± 10 % (75 Ω)
	Automatic equalizer 100 m (when using a cable)

Live Switcher -> Video Terminal -> HDMI IN	2 lines, HDMI 1.4b compatible
	Video format inputs:
	720p/59.94 Hz, 720p/50 Hz, 1080i/59.94 Hz, 1080i/50 Hz, 1080p/59.94 Hz, 1080p/50 Hz, 1080p/29.97 Hz, 1080p/25 Hz, 1080p/24 Hz, 1080p/23.98
	PC format inputs:
	re format inputs.
	WSXGA+ (1680 x 1050, 60 Hz), SXGA (1280 x 1024, 60 Hz), WXGA (1280 x 768, 60 Hz), XGA (1024 x 768, 60 Hz)
	Mode: Full/Fit-H/Fit-V
	• Connectors: HDMI x 2
	Equipped with frame synchronizer and simplified color corrector.
	The HDMI IN connector has scaler function.
	This connector does not support the HDCP technologies.
Live Switcher -> Video Terminal -> SI	* HDMI IN 1 excludes SDI IN 1.
OUT	
	• Connectors: BNC x 2
	• PGM, PVW, CLN, MV, AUX1/2, and Key Out can be assigned.
	[3G-SDI] 3G-SDI, SMPTE424M standard complied with (Compatible with Level-A)
	[3G-SDI] 3G-SDI, SMPTE424M standard complied with (Compatible with Level-A) $ \cdot 0.8 \ V \ [p-p] \pm 10 \ \% \ (75 \ \Omega) $
	• 0.8 V [p-p] ± 10 % (75 Ω)  [HD-SDI] HD-SDI, SMPTE292M standard
Live Switcher -> Video Terminal -> HDMI OUT	· 0.8 V [p-p] ± 10 % (75 Ω)
	$\cdot$ 0.8 V [p-p] $\pm$ 10 % (75 $\Omega$ ) [HD-SDI] HD-SDI, SMPTE292M standard $\cdot$ 0.8 V [p-p] $\pm$ 10 % (75 $\Omega$ )
	• 0.8 V [p-p] ± 10 % (75 Ω)  [HD-SDI] HD-SDI, SMPTE292M standard  • 0.8 V [p-p] ± 10 % (75 Ω)  1 line, HDMI 1.4b compatible
	<ul> <li>0.8 V [p-p] ± 10 % (75 Ω)</li> <li>[HD-SDI] HD-SDI, SMPTE292M standard</li> <li>0.8 V [p-p] ± 10 % (75 Ω)</li> <li>1 line, HDMI 1.4b compatible</li> <li>Connector: HDMI x 1</li> </ul>

Live Switcher -> Video Terminal -> LAN	Compatible with 1000Base-T and AUTO-MDIX (for IP signal transmission/control)
	• Connecting cable: LAN cable (Category 5e or more), max. 100 m (328 ft), STP (Shielded Twisted Pair) cable recommended
	• Connector: RJ-45
	IP input signal:
	Assigned to IN 6 to 9.
	• IN 6, IN 7: Selectable from SRT/NDI   HX (version1/version2).
	• IN 8, IN 9: Dedicated to High Bandwidth NDI input.
	Supports NDI $\alpha$ channel input. Used as a pair with IN 9 in this case.
	• IN6 to 9: High Bandwidth NDI x4 can be selected by changing to firmware that supports NDI HB mode.
	*For H.264, the AV-HSW10 supports input up to Level 4.2.
	For H.265, the AV-HSW10 supports input up to Level 5.1 (Main tier) and Level 4.1 (High tier).
	IP output signal:
	Assigned to OUT 4 and OUT 5.
	OUT 4, OUT 5: Selectable from SRT/High Bandwidth NDI/RTMP.
	• PGM, PVW, CLN, MV, AUX1/2, Key Out can be assigned.
	• Equipped with scaler function and i/p conversion function. *1
	• IN6 to IN9: When using firmware in NDI HB mode, only the High Bandwidth NDI of OUT4 is enabled.
	Possible output formats:
	1920 x 1080/60fps, 50fps, 30fps, 25fps, 24fps, 1280 x 720/60fps, 50fps
	*For H.264, the AV-HSW10 outputs at Level 4.2.

For H.265, the AV-HSW10 outputs at Level 5 (Main tier).

Live Switcher -> Video Terminal -> U	SBConnector for outputting UVC/UAC
	Assigned to OUT 6.
	Connector: USB3.2 Gen1 Type-C, No USB bus power functionality
	• PGM, PVW, CLN, MV, AUX1/2, and Key Out can be assigned.
	• Equipped with scaler function and i/p conversion function. *1
	Possible output formats:
	1920 x 1080/60fps, 50fps, 30fps, 25fps, 24fps, 1280 x 720/60fps, 50fps, 30fps, 25fps, 24fps
Live Switcher -> Video Terminal -> Signal Formats	3G-SDI
•	1080/59.94p, 50p, 29.97p, 25p, 24p, 23.98p
	1080/59.94i, 50i,
	720/59.94p, 50p
	NDI® High Bandwidth
	1080/59.94p, 50p, 29.97p, 25p, 24p, 23.98p
	720/59.94p, 50p
	NDI® HX
	1080/60p, 50p, 30p, 25p, 24p
	720p/60p, 50p
	USB
	1080/60p, 50p, 30p, 25p, 24p *1
Live Switcher -> Video Terminal ->	720p/60p, 50p, 30p, 25p, 24p [R:G:B] 4:4:4 8bit / 4:2:2 10bit (when HDMI)
Signal Processing	[Y:Cb:Cr] 4:2:2 8bit (when NDI® High Bandwidth/UVC)
	[Y:Cb:Cr] 4:2:0 8bit (when NDI® HX/SRT/RTMP)
	Nichol 400 10ki
Live Switcher -> Audio Terminal -> AUDIO IN	[Y:Cb:Cr] 4:2:2 10bit L/1 and R/2
	Connector: Pin jacks
	• Equipped with embedded functionality to each output.
	Equipped with delay/level adjustment function.

Live Switcher -> Audio Terminal -> AUDIO OUT	Connector for headphone monitor
	• Connector: Φ3.5 mm TRS
	Equipped with output volume adjustment function.
Live Switcher -> Synchronous Terminal -> REF Terminal Reference Input/ BB Outputs	In Genlock mode: Selectable from BB (black burst), Tri-level Sync, and internal synchronization
	• Loop-through output is performed in BB mode and Tri-level Sync mode.
	• If loop-through output is not going to be used, provide a 75 $\Omega$ termination.
	Connectors: BNC×2
	• Same field frequencies as those of the system formats supported.
	• For 23.98 Hz and 24 Hz, only Tri-level input or internal synchronization is supported.
Live Switcher -> Synchronous Terminal -> Video Delay Time	1 line (H)
	When the frame synchronizer setting is [Off] and neither the up-converter nor the down converter is operating
	1 frame (F)
	When the frame synchronizer setting is on and the up-converter and downconverter are operating $\frac{1}{2} \int_{-\infty}^{\infty} \frac{1}{2\pi} \left( \frac{1}{2} \int_{-\infty}^{\infty} \frac{1}{2\pi}$
	When the signals have passed through PinP, multi view, down-converter or HDMI IN/OUT, a maximum delay of 1 frame is applied in each case.
Live Switcher -> Control Terminal ->	Compatible with 1000Base-T and AUTO-MDIX (For IP control)
LAN Terminal	
	• Connecting cable: LAN cable (Category 5e), max. 100 m (328 ft), STP (Shielded Twisted Pair) cable recommended
	• Connector: RI-45
Live Switcher -> Control Terminal -> TALLY GPI Terminal	Connector: RJ-45 INPUT: 5 inputs, general-purpose, photocoupler sensing
	INPUT: 5 inputs, general-purpose, photocoupler sensing
	INPUT: 5 inputs, general-purpose, photocoupler sensing  OUTPUT: 8 outputs, selected from R/G tally, general-purpose
	INPUT: 5 inputs, general-purpose, photocoupler sensing  OUTPUT: 8 outputs, selected from R/G tally, general-purpose  ALARM: 1 output, open collector output (negative logic)
TALLY GPI Terminal Live Switcher -> Control Terminal -> USB Terminal	INPUT: 5 inputs, general-purpose, photocoupler sensing  OUTPUT: 8 outputs, selected from R/G tally, general-purpose  ALARM: 1 output, open collector output (negative logic)  • Connectors: D-Sub 15pin  • Connector: USB2.0, Type-A, with USB bus power functionality  Use a USB memory to save and load configuration files and still data, and perform firmwar updates.
TALLY GPI Terminal  Live Switcher -> Control Terminal -> USB Terminal  Live Switcher -> Audio	INPUT: 5 inputs, general-purpose, photocoupler sensing  OUTPUT: 8 outputs, selected from R/G tally, general-purpose  ALARM: 1 output, open collector output (negative logic)  • Connectors: D-Sub 15pin  • Connector: USB2.0, Type-A, with USB bus power functionality  Use a USB memory to save and load configuration files and still data, and perform firmwar updates.  IN: RCA x 2, OUT: 3.5 mm TRS
TALLY GPI Terminal  Live Switcher -> Control Terminal -> USB Terminal  Live Switcher -> Audio  Live Switcher -> Frame Synchronizer	INPUT: 5 inputs, general-purpose, photocoupler sensing  OUTPUT: 8 outputs, selected from R/G tally, general-purpose  ALARM: 1 output, open collector output (negative logic)  • Connectors: D-Sub 15pin  • Connector: USB2.0, Type-A, with USB bus power functionality  Use a USB memory to save and load configuration files and still data, and perform firmwar updates.  IN: RCA x 2, OUT: 3.5 mm TRS  All inputs
TALLY GPI Terminal  Live Switcher -> Control Terminal -> USB Terminal  Live Switcher -> Audio Live Switcher -> Frame Synchronizer Live Switcher -> CC/UC/DC (Input)	INPUT: 5 inputs, general-purpose, photocoupler sensing  OUTPUT: 8 outputs, selected from R/G tally, general-purpose  ALARM: 1 output, open collector output (negative logic)  • Connectors: D-Sub 15pin  • Connector: USB2.0, Type-A, with USB bus power functionality  Use a USB memory to save and load configuration files and still data, and perform firmwar updates.  IN: RCA x 2, OUT: 3.5 mm TRS  All inputs  i/P converter, DC/UC (1080-720P), CC
TALLY GPI Terminal  Live Switcher -> Control Terminal -> USB Terminal  Live Switcher -> Audio Live Switcher -> Frame Synchronizer Live Switcher -> CC/UC/DC (Input) Live Switcher -> Keyer	INPUT: 5 inputs, general-purpose, photocoupler sensing  OUTPUT: 8 outputs, selected from R/G tally, general-purpose  ALARM: 1 output, open collector output (negative logic)  • Connectors: D-Sub 15pin  • Connector: USB2.0, Type-A, with USB bus power functionality  Use a USB memory to save and load configuration files and still data, and perform firmwar updates.  IN: RCA x 2, OUT: 3.5 mm TRS  All inputs  i/P converter, DC/UC (1080-720P), CC  2 (PinP, Linear key, Luminance key, Chroma key*2)
Live Switcher -> Control Terminal -> USB Terminal  Live Switcher -> Audio Live Switcher -> Frame Synchronizer Live Switcher -> CC/UC/DC (Input) Live Switcher -> Keyer Live Switcher -> AUX	INPUT: 5 inputs, general-purpose, photocoupler sensing  OUTPUT: 8 outputs, selected from R/G tally, general-purpose  ALARM: 1 output, open collector output (negative logic)  • Connectors: D-Sub 15pin  • Connector: USB2.0, Type-A, with USB bus power functionality  Use a USB memory to save and load configuration files and still data, and perform firmwar updates.  IN: RCA x 2, OUT: 3.5 mm TRS  All inputs  i/P converter, DC/UC (1080-720P), CC  2 (PinP, Linear key, Luminance key, Chroma key*2)
Live Switcher -> Control Terminal -> USB Terminal  Live Switcher -> Audio Live Switcher -> Frame Synchronizer Live Switcher -> CC/UC/DC (Input) Live Switcher -> Keyer Live Switcher -> AUX Live Switcher -> Genlock	INPUT: 5 inputs, general-purpose, photocoupler sensing  OUTPUT: 8 outputs, selected from R/G tally, general-purpose  ALARM: 1 output, open collector output (negative logic)  • Connectors: D-Sub 15pin  • Connector: USB2.0, Type-A, with USB bus power functionality  Use a USB memory to save and load configuration files and still data, and perform firmwal updates.  IN: RCA x 2, OUT: 3.5 mm TRS  All inputs i/P converter, DC/UC (1080-720P), CC  2 (PinP, Linear key, Luminance key, Chroma key*2)  2  BB or Tri-level (Input/through output)
TALLY GPI Terminal  Live Switcher -> Control Terminal -> USB Terminal  Live Switcher -> Audio Live Switcher -> Frame Synchronizer Live Switcher -> CC/UC/DC (Input) Live Switcher -> Keyer Live Switcher -> AUX Live Switcher -> Genlock Live Switcher -> PTZ Link	INPUT: 5 inputs, general-purpose, photocoupler sensing  OUTPUT: 8 outputs, selected from R/G tally, general-purpose  ALARM: 1 output, open collector output (negative logic)  • Connectors: D-Sub 15pin  • Connector: USB2.0, Type-A, with USB bus power functionality  Use a USB memory to save and load configuration files and still data, and perform firmwar updates.  IN: RCA x 2, OUT: 3.5 mm TRS  All inputs i/P converter, DC/UC (1080-720P), CC  2 (PinP, Linear key, Luminance key, Chroma key*2)  2  BB or Tri-level (Input/through output)  RP Link (AW-RP60/ RP150), TSL5.0
Live Switcher -> Control Terminal -> USB Terminal  Live Switcher -> Audio Live Switcher -> Frame Synchronizer Live Switcher -> CC/UC/DC (Input) Live Switcher -> Keyer Live Switcher -> AUX Live Switcher -> Genlock	INPUT: 5 inputs, general-purpose, photocoupler sensing  OUTPUT: 8 outputs, selected from R/G tally, general-purpose  ALARM: 1 output, open collector output (negative logic)  • Connectors: D-Sub 15pin  • Connector: USB2.0, Type-A, with USB bus power functionality  Use a USB memory to save and load configuration files and still data, and perform firmwal updates.  IN: RCA x 2, OUT: 3.5 mm TRS  All inputs i/P converter, DC/UC (1080-720P), CC  2 (PinP, Linear key, Luminance key, Chroma key*2)  2  BB or Tri-level (Input/through output)

1. Planned support with a firmware update